



# **BOUNCE AROUND**

**PLEASE READ CAREFULLY**

- 1) This product has a repair kit which contains one transparent patch label.
- 2) This product is designed for use indoors/outdoors and on a smooth, level surface. The play area should be cleared of any sharp-edged objects, stones, etc. Do not use near any obstructions such as walls, tables, chairs or any object that could cause injury if a child fell against or onto it.
- 3) Children should remove shoes and any sharp, pointed objects such as buckles on belts, etc.
- 4) This product is not to be used in water.

**THIS TOY MUST BE USED UNDER  
CONSTANT ADULT SUPERVISION**

## **Inflation Instructions:**

This product must be inflated by an adult using a hand or foot pump. Do not use high pressure compressors as over inflation will cause permanent damage to the seams. As a guide, the chamber should be firm but not hard to the touch.

After inflating each chamber, check to be sure the end plugs are fully inserted into the valve and that the valve is pushed into the body of the chamber.

## **Deflation and storage instructions:**

Squeeze the base of the valve to release the air. Do not insert objects into the valve as this could cause permanent damage.

When deflated, and before folding, be sure that all surfaces are clean, dry and free from any sharp objects.



**KEEP AWAY FROM FIRE!!!**